


Description of options



Option H5, CANbus J1939 Generator Controller GC-1F

4189340474A
SW 1.0X.X



- *Description of option*
- *Functional descriptions*
- *Parameter list*



Table of contents

1. WARNINGS AND LEGAL INFORMATION	3
LEGAL INFORMATION AND RESPONSIBILITY	3
ELECTROSTATIC DISCHARGE AWARENESS	3
SAFETY ISSUES	3
FACTORY SETTINGS	3
DEFINITIONS	3
2. DESCRIPTION OF OPTION	4
OPTION H5	4
HARDWARE	4
WIRINGS	5
3. FUNCTIONAL DESCRIPTIONS	7
ALARM ENABLING/DISABLING	7
VIEWS AVAILABLE ON THE DISPLAY	8
DISPLAY FUNCTIONS	9
ICON LIST	10
RUNNING DETECTION	13
4. PARAMETER LIST	14
OVERVIEW TABLE	14
PARAMETER TABLES	15

1. Warnings and legal information

Legal information and responsibility

DEIF takes no responsibility for installation or operation of the engine set. If there is any doubt about how to install or operate the engine controlled by the unit, the company responsible for the installation or the operation of the set must be contacted.

The units are not to be opened by unauthorised personnel. If opened anyway, the warranty will be lost.

Electrostatic discharge awareness

Sufficient care must be taken to protect the terminals against static discharges during the installation. Once the unit is installed and connected, these precautions are no longer necessary.

Safety issues

Installing the unit implies work with dangerous currents and voltages. Therefore, the installation should only be carried out by authorised personnel who understand the risks involved in working with live electrical equipment.



Be aware of the hazardous live currents and voltages. Do not touch any AC measurement inputs as this could lead to injury or death.

Factory settings

The unit is delivered with certain factory settings. Given the fact that these settings are based on average values, they are not necessarily the correct settings for matching the individual engine. Thus precautions must be taken to check the settings before running the engine.

Definitions

Throughout this document a number of notes and warnings will be presented. To ensure that these are noticed, they will be highlighted in order to separate them from the general text.

Notes



The notes provide general information, which will be helpful for the reader to bear in mind.

Warning



The warnings indicate a potentially dangerous situation, which could result in death, personal injury or damaged equipment, if certain guidelines are not followed.

2. Description of option

Option H5

Option H5 is a software option. Option H5 contains a communication slot with the possibility of connecting the unit to a variety of CANbus engine communication systems.

Option H5 extracts information from the Electronic Control Module (ECM) of an engine equipped with a CANbus interface from one of the following engine manufacturers:

- Detroit Diesel (DDEC communication)
- Deutz (EMR CANbus communication)
- John Deere (JDEC communication)
- Volvo (Volvo Penta D12 AUX communication)
- Scania (Scania EMS communication)

The controller unit needs to be set up for the engine communication type required in the individual application. This is done in parameter menu 4771 via the PC utility software.

All these protocols are based on the CANbus communication system. The Baud rate is fixed by the engine manufacturer at:

DDEC	EMR	JDEC	Volvo Penta	Scania EMS
250kBit/s	250kBit/s	250kBit/s	250kBit/s	250kBit/s

When the GC-1F is equipped with option H5, it will be able to dedicate some relay outputs controlled by the level detection or binary information of selected information:


- Communication error
- EIC shutdown (Engine Interface Communication)
- Overspeed
- Coolant temperature (2 levels)
- Oil pressure (2 levels)

Hardware

The EIC (Engine Interface Communication) is performed via terminals 55, 54 and 53:


Terminal	Description
55	CAN-L
54	CAN common
53	CAN-H

An overview of the terminals can be seen below. The slots are positioned in the unit as follows (rear of the unit):




Wirings

Principle diagram:



Connection diagram:




3. Functional descriptions

Alarm enabling/disabling

Refer to the Installation Instructions and Reference Handbook, chapter Utility software configuration.

If an alarm is enabled, it can be inhibited. The configuration of this inhibit function is selectable by means of the utility software in the menu line Settings/Inhibits.

The illustration below shows the inhibit EI alarms located in the I/O settings.



Views available on the display

Object	DDEC	EMR	JDEC	Volvo Penta	Scania EMS
Speed	Available	Available	Available	Available	Available
Coolant temp.	Available	Available	Available	Available	Available
Oil pressure	Available	Available	Available	Available	Available
EIC: Faults	N. A.	Available	N. A.	N. A.	N. A.
EIC: Oil temp.	Available	N. A.	N. A.	Available	Available
EIC: Fuel temp.	Available	N. A.	Available	N. A.	N. A.
EIC: Boost pressure	Available	N. A.	N. A.	Available	Available
EIC: Air inlet temp.	Available	N. A.	N. A.	N. A.	N. A.
EIC: Coolant level	Available	N. A.	N. A.	Available	Available
EIC: Fuel rate	Available	N. A.	Available	Available	Available
EIC: Charge air pressure	N. A.	N. A.	N. A.	N. A.	N. A.
EIC: Charge air temp.	N. A.	N. A.	Available	Available	Available
EIC: Air inlet pressure	N. A.	N. A.	N. A.	Available	N. A.
EIC: Exhaust gas temp.	N. A.	N. A.	N. A.	Available	N. A.
EIC: Engine hours	N. A.	N. A.	N. A.	Available	N. A.
EIC: Oil f. diff. press.	N. A.	N. A.	N. A.	Available	N. A.
EIC: Battery voltage	N. A.	N. A.	N. A.	Available	N. A.
EIC: Fuel del. press.	N. A.	N. A.	N. A.	Available	N. A.
EIC: Oil level	N. A.	N. A.	N. A.	Available	N. A.
EIC: Crankcase press.	N. A.	N. A.	N. A.	Available	N. A.
EIC: Coolant pressure	N. A.	N. A.	N. A.	Available	N. A.
EIC: Water in. fuel	N. A.	N. A.	N. A.	Available	N. A.




- All the display values corresponding to this option H5 have a description beginning with 'EIC'.
- If a view line is not available, it will not be shown.
- If the value for an available view line is not available due to some type of error in the sensor, sub-system or module, '--' is shown.
- If the value for an available view line is not available (e.g. due to a communication error), the value field is exchanged with '—'.
- The menu 6001 (Engine I. Comm.) is affecting the shown value on the display.

Display functions


The display indicates both readings and alarms. Illustrated below are examples with icons and English language.



Type and software version.




Battery voltage, RPM and running hours counter.




Service timer 1 and 2.

Date and time.




Press to enter the list of active alarms.



Active alarm list. The alarm list pops up automatically, when an alarm appears. When the arrow is present, more alarms are active. Press to scroll through the list. Exit the list by pressing ESC.



Press to enter the parameter setting.



Min. value

Actual value

Max. value

Parameter example: D+ delay setting. Use or to scroll through the settings list. If change of settings is necessary, press and enter the password. Then use or to change values. Use ESC to leave settings.




The available parameters depend on the set options. Some parameters can only be changed using the PC utility software (USW) for GC-1F. The parameter list will automatically be abandoned, if no button is pressed during a 30 sec. period.

Icon list



The list covers all available icons including those not related to the engine communication.

	Warning list	Icon
1	Low oil pressure warning	
2	EIC temp. lube oil	
3	High coolant temp. warning	
4	High intercooler temp.	
5	Defect coolant level switch	
6	EMR warning	
7	JDEC warning	
8	Oil pressure	
9	Intake manifold	
10	Coolant temperature	
11	Fuel injection pump	
12	EI Comm. error	
13	EIC warning	
14	Stop limit exceeded	
15	EMS warning	
16	Charge 61	

	Shutdown list	Icon
17	Overspeed shutdown	
18	Low oil pressure shutdown	
19	EIC temp. lube oil	
20	Low coolant level shutdown	
21	High coolant temp. shutdown	
22	High oil temp. shutdown	
23	High charge air temp. shutdown	
24	High coolant temp. shutdown	
25	EMR shutdown	
26	JDEC shutdown	
27	Fuel temperature	
28	Fuel control valve	
29	ECU failure	
30	EIC shutdown	
31	EMS shutdown	

	Analogue readings	Icon
32	EIC speed	
33	EIC coolant temp.	
34	EIC oil pressure	
35	EIC faults	
36	EIC oil temp.	
37	EIC fuel temp.	
38	EIC boost pressure	
39	EIC air inlet temp.	
40	EIC coolant level	
41	EIC fuel rate	
42	EIC charge air pressure	
43	EIC charge air temp.	
44	EIC air inlet pressure	
45	EIC exhaust gas temp.	
46	EIC engine hours	
47	EIC oil f. diff. press.	
48	EIC battery voltage	
49	EIC fuel del. press.	

50	EIC oil level	
51	EIC crankcase press.	
52	EIC coolant pressure	
53	EIC water in. fuel	

Running detection

During a start sequence the start relay is deactivated, if:

- the speed exceeds the RPM running setting
- the running feedback input is ON, or
- the measured frequency of the generator is above 30Hz, or
- the speed information given by the EIC communication is above the limit 6010 EIC overspeed

During a stop sequence the generator is considered to be stopped, if:

- the speed is below the running setting
- the running feedback input is OFF, or
- the measured frequency of the generator is below 30Hz, or
- the speed information given by the EIC communication is below the limit 6010 EIC overspeed

4. Parameter list

The engine communication setup is performed through the display or the PC utility software.



Please notice that only the engine type can be set on the display, other possible settings can only be set via the PC utility software.

Parameter table description

The table consists of the following possible adjustments:

Set point: The alarm set point is adjusted in the set point menu. The setting is a percentage of the nominal values.

Timer: The timer setting is the time that must expire from the alarm level is reached until the alarm occurs.

Relay output A: A relay can be activated by output A.

Relay output B: A relay can be activated by output B.

Enable: The alarm can be activated or deactivated. ON means always activated, RUN means that the alarm has run status. This means it is activated, when the running signal is present.

Fail class: When the alarm occurs, the unit will react depending on the selected fail class.



Small differences due to the character of the parameters may exist between the individual tables.

Overview table

7570 EIC overspeed	7630 EIC temp. lube 2
7580 EIC coolant temp. 1	7640 EI communication error
7590 EIC coolant temp. 2	7650 EIC shutdown
7600 EIC oil pressure 1	7660 EIC warning
7610 EIC oil pressure 2	7980 Engine communications
7620 EIC temp. lube 1	

Parameter tables

7570 EIC overspeed

No.	Setting		Min. setting	Max. setting	Factory setting
7571	EIC overspeed	Set point	0 RPM	2000 RPM	1600 RPM
7572	EIC overspeed	Delay	0.0 s	100.0 s	2.0 s
7573	EIC overspeed	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7574	EIC overspeed	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7575	EIC overspeed	Enable	OFF	RUN	OFF
7576	EIC overspeed	Fail class	See description of fail classes		Warning

7580 EIC coolant temp. 1

No.	Setting		Min. setting	Max. setting	Factory setting
7581	EIC cool w. t. 1	Set point	-40 deg.	210 deg.	100 deg.
7582	EIC cool w. t. 1	Delay	0.0 s	100.0 s	5.0 s
7583	EIC cool w. t. 1	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7584	EIC cool w. t. 1	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7585	EIC cool w. t. 1	Enable	OFF	RUN	OFF
7586	EIC cool w. t. 1	Fail class	See description of fail classes		Warning

7590 EIC coolant temp. 2

No.	Setting		Min. setting	Max. setting	Factory setting
7591	EIC cool w. t. 2	Set point	-40 deg.	210 deg.	110 deg.
7592	EIC cool w. t. 2	Delay	0.0 s	100.0 s	5.0 s
7593	EIC cool w. t. 2	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7594	EIC cool w. t. 2	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7595	EIC cool w. t. 2	Enable	OFF	RUN	OFF
7596	EIC cool w. t. 2	Fail class	See description of fail classes		Shutdown

7600 EIC oil pressure 1

No.	Setting		Min. setting	Max. setting	Factory setting
7601	EIC oil press. 1	Set point	0.0 bar	10.0 bar	2.0 bar
7602	EIC oil press. 1	Delay	0.0 s	100.0 s	5.0 s
7603	EIC oil press. 1	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7604	EIC oil press. 1	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7605	EIC oil press. 1	Enable	OFF	RUN	OFF
7606	EIC oil press. 1	Fail class	See description of fail classes		Warning

7610 EIC oil pressure 2

No.	Setting		Min. setting	Max. setting	Factory setting
7611	EIC oil press. 2	Set point	0.0 bar	10.0 bar	1.0 bar
7612	EIC oil press. 2	Delay	0.0 s	100.0 s	5.0 s
7613	EIC oil press. 2	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7614	EIC oil press. 2	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7615	EIC oil press. 2	Enable	OFF	RUN	OFF
7616	EIC oil press. 2	Fail class	See description of fail classes		Shutdown

7620 EIC temp. lube 1

No.	Setting		Min. setting	Max. setting	Factory setting
7621	EIC temp. lube 1	Set point	0 deg.	300 deg.	40 deg.
7622	EIC temp. lube 1	Delay	0.0 s	100.0 s	5.0 s
7623	EIC temp. lube 1	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7624	EIC temp. lube 1	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7625	EIC temp. lube 1	Enable	OFF	RUN	OFF
7626	EIC temp. lube 1	Fail class	See description of fail classes		Warning

7630 EIC temp. lube 2

No.	Setting		Min. setting	Max. setting	Factory setting
7631	EIC temp. lube 2	Set point	0 deg.	300 deg.	50 deg.
7632	EIC temp. lube 2	Delay	0.0 s	100.0 s	5.0 s
7633	EIC temp. lube 2	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7634	EIC temp. lube 2	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7635	EIC temp. lube 2	Enable	OFF	RUN	OFF
7636	EIC temp. lube 2	Fail class	See description of fail classes		Shutdown

7640 EI communication error

No.	Setting		Min. setting	Max. setting	Factory setting
7641	EI comm. error	Delay	0.0 s	100.0 s	0.0 s
7642	EI comm. error	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7643	EI comm. error	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7644	EI comm. error	Enable	OFF	RUN	OFF
7645	EI comm. error	Fail class	See description of fail classes		Warning

Below is a list of warning information that can be shown on the display depending on the engine communication type:

	Warning list	DDEC	EMR	JDEC	Volvo Penta	Scania EMS
1	Low oil pressure warning	-	-	x	-	x
2	High coolant temp. warning	-	-	x	-	x
3	EMR warning	-	x	-	-	-
4	JDEC warning	-	-	x	-	-
5	Intake manifold	-	-	x	-	-
6	Fuel injection pump	-	-	x	-	-
7	Charge 61	-	-	-	-	x
8	EMS warning	-	-	-	-	x
9	Stop limit exceeded	-	-	-	-	x

7650 EIC shutdown

No.	Setting		Min. setting	Max. setting	Factory setting
7651	EIC shutdown	Delay	0.0 s	100.0 s	0.0 s
7652	EIC shutdown	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7653	EIC shutdown	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7654	EIC shutdown	Enable	OFF	RUN	OFF
7655	EIC shutdown	Fail class	See description of fail classes		Shutdown

All shutdown alarms are grouped in this menu.

7660 EIC warning

No.	Setting		Min. setting	Max. setting	Factory setting
7661	EIC warning	Delay	0.0 s	100.0 s	0.0 s
7662	EIC warning	Relay output A	R0 (none)	R5 (relay 5)	R0 (none)
7663	EIC warning	Relay output B	R0 (none)	R5 (relay 5)	R0 (none)
7664	EIC warning	Enable	OFF	RUN	OFF
7665	EIC warning	Fail class	See description of fail classes		Warning


All warning alarms are grouped in this menu. Below is a list of the shutdown alarms included in this group depending on engine communication type:

	Shutdown list	DDEC	EMR	JDEC	Volvo Penta	Scania EMS
1	Overspeed shutdown	-	X	-	-	-
2	Low oil pressure shutdown	-	X	X	-	-
3	High coolant temp. shutdown	-	X	X	-	-
4	EMR shutdown	-	X	-	-	-
5	JDEC shutdown	-	-	X	-	-
6	Fuel temperature	-	-	X	-	-
7	Fuel control valve	-	-	X	-	-
8	ECU failure	-	-	X	-	-
9	EMS shutdown	-	-	-	-	x

7980 Engine communications

7981	Engine comm.	OFF	DDEC	EMR	JDEC	Volvo Penta	Scania EMS
------	--------------	-----	------	-----	------	-------------	------------

The illustration below shows **7980 Engine communications** in the PC utility software.



The engine communication collects data from the engine. Some of the data can be used as alarm inputs.

DEIF A/S reserves the right to change any of the above