


Application Notes

Automatic Gen-set Controller

4189340430A

SW version 3.0X.X



- *Single generator set*
- *Automatic mains failure*
- *Parallel with mains (grid)*
- *Load sharing, multiple gen-sets*
- *Sensors*



Table of contents

1. ABOUT THIS DOCUMENT.....	4
GENERAL PURPOSE.....	4
INTENDED USERS	4
CONTENTS/OVERALL STRUCTURE.....	4
2. WARNINGS AND LEGAL INFORMATION	5
LEGAL INFORMATION AND RESPONSIBILITY	5
ELECTROSTATIC DISCHARGE AWARENESS	5
SAFETY ISSUES	5
DEFINITIONS	5
3. SINGLE GENERATOR SET	6
SYSTEM SINGLE-LINE DIAGRAM	6
AC CONNECTIONS	7
DC CONNECTIONS.....	8
4. AUTOMATIC MAINS FAILURE.....	9
SYSTEM SINGLE-LINE DIAGRAM	9
AC CONNECTIONS	10
DC CONNECTIONS.....	11
5. PARALLEL WITH MAINS (GRID)	12
SYSTEM SINGLE-LINE DIAGRAM	12
AC CONNECTIONS	13
DC CONNECTIONS.....	14
6. LOAD SHARING.....	15
SYSTEM SINGLE-LINE DIAGRAM	15
AC CONNECTIONS	16
DC CONNECTIONS.....	17
ADDITIONAL DC CONNECTIONS	18
7. PT100/PT1000 SENSORS.....	19
INTRODUCTION.....	19
CONNECTIONS	19
8. VDO SENSORS	20
INTRODUCTION.....	20
CONNECTIONS	20
9. 4-20MA INPUTS.....	21
INTRODUCTION.....	21
CONNECTIONS	21
10. DIGITAL INPUTS	23
INTRODUCTION.....	23
CONNECTION	23

11.	0-40V DC	25
	INTRODUCTION.....	25
	CONNECTION	25
12.	OTHER INPUTS/OUTPUTS.....	26
	OPTOCOUPLER OUTPUTS.....	26

1. About this document

General purpose

This document includes application notes for DEIF's Automatic Gen-set Controller, the AGC. It mainly includes examples of different applications suitable for the unit.



For functional descriptions, the procedure for parameter setup, complete standard parameter lists etc., please see the Designer's Reference Handbook.

The general purpose of the Application Notes is to offer the designer information about suitable applications for the AGC.



Please make sure to read this handbook before working with the multi-line 2 controller and the gen-set to be controlled. Failure to do this could result in damage to the equipment or human injury.

Intended users

The Application Notes is mainly intended for the person responsible for designing AGC systems. In most cases, this would be a panel builder designer. Naturally, other users might also find useful information in this document.

Contents/overall structure

The Application Notes is divided into chapters and in order to make the structure of the document simple and easy to use, each chapter will begin from the top of a new page.

2. Warnings and legal information

Legal information and responsibility

DEIF takes no responsibility for installation or operation of the generator set. If there is any doubt about how to install or operate the generator set controlled by the unit, the company responsible for the installation or the operation of the set must be contacted.

The units are not to be opened by unauthorised personnel. If opened anyway, the warranty will be lost.

Electrostatic discharge awareness

Sufficient care must be taken to protect the terminals against static discharges during the installation. Once the unit is installed and connected, these precautions are no longer necessary.

Safety issues

Installing the unit implies work with dangerous currents and voltages. Therefore, the installation should only be carried out by authorised personnel who understand the risks involved in working with live electrical equipment.



Be aware of the hazardous live currents and voltages. Do not touch any AC measurement inputs as this could lead to injury or death.

Definitions

Throughout this document a number of notes and warnings will be presented. To ensure that these are noticed, they will be highlighted in order to separate them from the general text.

Notes



The notes provide general information which will be helpful for the reader to bear in mind.


Warning




The warnings indicate a potentially dangerous situation which could result in death, personal injury or damaged equipment, if certain guidelines are not followed.

3. Single generator set

System single-line diagram



AC connections




A neutral connection is a possibility but not a necessity. AC voltages max. 690V AC phase-phase.



Regarding single phase and split phase (2 phase) systems, please refer to the Installation Instructions.


DC connections

Engine interface PCB




4. Automatic mains failure

System single-line diagram



AC connections




A neutral connection is a possibility but not a necessity. AC voltages max. 690V AC phase-phase.



Regarding single phase and split phase (2 phase) systems, please refer to the Installation Instructions.

DC connections

Engine interface PCB




5. Parallel with mains (grid)


This application covers the gen-set modes peak shaving, fixed power, mains power export and load take over.

The application can be combined with the stand-by AMF (Automatic Mains Failure) application by enabling the mode shift setting. In this case, the unit will automatically run the generator as a stand-by AMF generator in case of mains failure.

System single-line diagram



AC connections




A neutral connection is a possibility but not a necessity. AC voltages max. 690V AC phase-phase.



Regarding single phase and split phase (2 phase) systems, please refer to the Installation Instructions.

DC connections


Engine interface PCB




In peak shaving, mains power export and load take over, it is necessary to connect a 4-20mA signal from a power transducer to multi input 1 as the mains power measurement.

6. Load sharing

System single-line diagram



AC connections




A neutral connection is a possibility but not a necessity. AC voltages max. 690V AC phase-phase.



Regarding single phase and split phase (2 phase) systems, please refer to the Installation Instructions.

DC connections

Engine interface PCB




Additional DC connections

Load sharing connections

In theory, the load sharing lines have no maximum distance. The impedance of the input of the load sharing line is 22k Ω . As a consequence, the resistance of the selected cable is insignificant.

A load sharing line of up to 300 metres is commonly used, but 300 metres is not the limit.



Use screened cable only.



Load sharing requires option G3.

7. PT100/PT1000 sensors

Introduction

The PT100 and PT1000 inputs are available on the multi inputs in slot #7.




PT100 and PT1000 sensors are also known as RTD sensors (Resistance Temperature Detector).


Connections

The input is designed for the 3-wire sensor, but the 2-wire sensor can also be used. The unit will also measure the resistance of the leads and cables. The 3-wire sensor compensates for the resistance of the leads and cables and gives a more accurate measurement than the 2-wire sensor.

2-wire connections



3-wire connections



8. VDO sensors


Introduction

The VDO inputs are available on the multi inputs in slot #7.

Connections


1-wire sensors

This diagram shows how the 1-wire VDO sensors must be connected.



2-wire sensor

This diagram shows how the 2-wire VDO sensors must be connected.



The measurement is only a resistance measurement. It is not necessary to connect an auxiliary supply to the sender.

9. 4-20mA inputs

Introduction


The 4-20mA inputs are available on the multi inputs in slot #7 and in slot #6, if option M15 is chosen.

Connections

Multi inputs

Passive transducers


If the passive 4-20mA transducers are used, the following connection must be used.



If the passive sensor has its own battery supply, the voltage may not exceed 30V DC.

Active transducers

Active transducers are connected like this:




Analogue inputs (option M15)

The following drawings only show the wiring for analogue input 91, but apply to all analogue inputs (91 to 97) included in option M15.

Passive transducers


If the passive 4-20mA transducers are used, then the following connection must be used.



If the passive sensor has its own battery supply, the voltage may not exceed 30V DC.


Active transducers

Active transducers are connected like this:



0-10V DC

Under certain circumstances, the 4-20mA input can be used to measure a 0-10V DC signal.



The unit will measure 0-20mA, but it will only use the 4-20mA range for protection purposes.

10. Digital inputs

Introduction


The digital inputs can be used as protection inputs or as function/control inputs. The protection inputs can be used as normally open or normally closed. When used as function/control inputs, they depend on the specific function and how the function is activated.



See a complete list of the digital inputs and input functions in the Designer's Reference Handbook.


Connection

Multi inputs




The resistor is only mounted if wire fail supervision is required. The value of the resistor should be $270\Omega \pm 10\%$.

Battery positive to input



Battery negative to input


It may be practical to connect the battery positive to the unit common. The clear advantage is that digital sensors can be used, e.g. for water temperature or oil pressure that has the sensor body connected to earth.



The digital inputs are bi-directional.

Emergency stop

Since the start prepare relay and run coil are supplied through terminal 118, this terminal should only be used for the emergency stop.



It is not possible to connect the emergency stop input to battery negative.


11. 0-40V DC

Introduction

The 0-40V DC inputs can be used for battery charger alarms, battery asymmetry or protections. The inputs are only available on the multi inputs in slot #7.

Connection

Multi input




12. Other inputs/outputs



Optocoupler outputs

When the transistor outputs are configured to 'Relay', it is possible to use the transistor outputs as relay outputs. As these outputs are open collector outputs, the wiring should be done as shown below.

External counter:





Relay output:



Remember to mount the free wheel diode.



Maximum load on the optocoupler outputs is 10mA at 24V DC.

External set point inputs (option G3)**0-10V DC input using potentiometer****+/-10V DC input using potentiometer**

DEIF A/S reserves the right to change any of the above